



Notes

1. Any infiltration trench or raingarden shall be at least 10 feet away from any foundation wall.
2. At grade overflow shall be provided for all downspout connections.



**Infiltration Trench
(for small sites)**

Date Revised
August 2014

Plate Number
3340-07

Sheet 1 of 1

